















Outdoor Wicker Set

SKU# 2245




ASSEMBLY MANUAL


The parts and hardware below have been included for assembly:




STEP 1



STEP 2




STEP 3




This will complete Assembly 1. Repeat this process for other half of the chair to complete assembly 2. Next, proceed to step 4.


STEP 4



STEP 5



STEP 6



Use part (H) to secure the back rest when positioned completely upward and completely down. Lastly, slide part (L) underneath both sides of the chair.

WARNING:

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.



..... *Call Us!*

WE'RE HERE 7 DAYS A WEEK TO HELP YOU!

..... **(844)-948-8400**

MONDAY-FRIDAY 5:00AM-10:30PM PST
SATURDAY AND SUNDAY 7:00AM-3:30PM PST